



PLEASE READ CAREFULLY BEFORE USE OF OUR PRODUCT

PRODUCT DESCRIPTION

Liquid Shield is an advanced nano coating that is designed to preserve the condition of your jewelry, protect it from everyday use, and provide excellent scratch resistant protection. Each kit is designed for multiple applications.

WHAT IS INCLUDED

- 1x Bottle of Liquid Shield
- 1x Large microfiber work mat
- 1x Small microfiber cloth
- 1x Pair of disposable gloves
- 4x Cleaning prep wipes
- 2x Double sided applicator sticks
- 1x Drying stand

BEFORE APPLICATION

Your jewelry will be preserved in its existing condition once the coating has cured. For this reason we recommend polishing any major scratches out PRIOR to application if possible. OPTIMAL application temperature is between 65 to 75 degrees Fahrenheit.

WARNING

Once Liquid Shield is applied and fully cured, it can only be removed by machine polishing. Failing to follow proper guidelines may result in loss of coating strength.

CAUTION

Hand and skin protection is recommended. Work in a ventilated area. Store in a dry cool place away from ambient lighting. Keep out of reach of children. Do not inhale or swallow. To avoid chance of skin irritation, only apply coating on the outside of jewelry that does not come into contact with your skin.


DISCLAIMER

Although its unlikely, we are not responsible for voiding any warranty for the watch or jewelry with the use of this product, not responsible for any damage that may occur during or after application, not responsible for any skin irritation, illness, or death due to improper use of our product.

APPLICATION INSTRUCTIONS

1. PREP

- Lay out the large microfiber mat and put on gloves.
- Shake Liquid Shield bottle for 30 seconds.
- Clean surface with alcohol wipe and dry with mat.
- Surface must be completely dry before proceeding.



2. APPLY

- Dampen 1 applicator tip from the bottle and apply to the surface using a circular motion.
- Wait 5 to 7 minutes before proceeding to step three.



3. SHINE

- Use the small black cloth to wipe surface in a circular motion, leveling the coating until desired finished is reached.



IF YOU MAKE ANY MISTAKES DURING THE APPLICATION PROCESS, USE THE ALCOHOL WIPE TO REMOVE COATING WITHIN 15 MINUTES OF APPLICATION.

The coating will be dry to the touch after 45 minutes. Multiple coats will increase protection against scratches. Repeat steps 2 to 3 for each additional coat and wait 45 minutes between applications.

Liquid Shield will be fully cured after 1 week.

For further assistance, view our application video, FAQ page, or Safety Data Sheet, visit our website: WWW.LIQUIDSHIELD.CO